

## SXP118 and SXP218 Firmware 1.1.43

---

This firmware fixes the following issues with newer versions of SXP118 and SXP218 (and also CDD-LIVE 8, 12 and 15):

- Low level noise if you set the speaker fader to very low levels.
- Wrong phase for SXP118 and SXP218. This issue also impacted CDD-LIVE 12 and 15, but not CDD-LIVE 8. This only caused a problem if you combined SXP118 and SXP218 with speakers other than CDD-LIVE 12 and 15.

### To find out if you need to upgrade firmware

Check the serial numbers on the back of your speakers (or in Vu-Net). Find the characters BR near the middle of the serial number. If the next character is P or later in the alphabet (P to Z), the speaker is impacted and you need to upgrade firmware.

For example, with serial number ASM20006BRPQ0068 you need to upgrade due to the P after the BR.

### To upgrade firmware

1. Connect your speakers to Vu-Net.
2. Click **Get Firmware Updates** (bottom right of the screen).
3. Click **DOWNLOAD THE LATEST FIRMWARE FILES**.
4. Click **PROCEED WITH FIRMWARE UPGRADE USING VUNET FIRMWARE DATABASE**.
5. Select the speakers to upgrade.
6. If the right-hand column **Upgrade available** is **NO** then the speaker isn't impacted and you don't need to upgrade firmware; you can just click **Cancel** to exit this screen.
7. If the right-hand column shows **1.1.43**, click **Next** to upgrade firmware.
8. Check the status message at the end of the process.
9. If the status is shown as unsuccessful, run the upgrade again. Note that when you do this, the right-hand column **Upgrade available** will show **NO** (as the firmware will have part-upgraded to 1.1.43). Despite this, select **Next** to run the upgrade to 1.1.43 again.